RF CCT Color Controller

09.2855W.04211

FC CE ✔RoHS COMPLIANT ⓊL ⓉⓊⓋ

Important: Read All Instructions Prior to Installation

Function introduction

Press and hold down to increase light intensity

Press and hold down to decrease light intensity

Click to switch on/off

Control the receiver's cw channel, Press and hold down to increase/ decrease light intensity

Control the receiver's ww channel, Press and hold down to increase/ decrease light intensity

Front side

CR2430 battery

Back side

Product Data

Output	RF signal
Operation Frequency	869.5/434MHz
Power Supply	3V(CR2430 battery)
Operating temperature	0-40°C
Relative humidity	8% to 80%
Dimensions	55x55x11.1mm

• Control 1 zone
• CCT color controller
• Memory Function
• Compatible with all universal series RF receivers
• 1 receiver can be paired by max 8 different remote controls.
• Waterproof grade: IP20

Safety & Warnings

• This device contains a button lithium battery that shall be stored and disposed properly.
• DO NOT expose the device to moisture.

Operation

1. Pair with RF receivers:

Turn on the remote → Click **"Learning Key"** on RF receiver → Click any of the four buttons CW WW ✳ ✴ → LED lights connected with the RF receiver will flicker once

→ The receiver is paired with the remote successfully.

How to delete the pairing:
Press and hold down **"Learning Key"** on the receiver for over 3 seconds until connected LED lights flicker twice, which means the pairing is deleted successfully.